

# H.K Series



**F341**  
20 A Control Switches  
Bs. 3676  
1 Gang DP, with indicator lamp



**F239L**  
13 Amp. Switched socket outlets.  
Bs. 1363  
1 Gang, with lamp indicator  
Fitted with safety shutter



**F239**  
13 Amp. Switched socket outlets.  
Bs. 1363  
1 Gang  
Fitted with safety shutter



**F230B**  
10 Amp. Push button  
Retractive switches.  
Bs. 3676  
1 Gang marked with bell symbol  
can be wired for (N/O) or (N/C)